

# Taster Pad – links/rechts

# Trigger Pad – left/right



## Technische Daten

## Technical data

<b>Mindesthaltbarkeit</b>	8 Monate
<b>Minimum durability</b>	8 months

---

### Mechanische Daten

### Mechanical data

Abmessung	94 x 79 x 6 mm
Dimensions (lxbxh)	
Gewicht	7 g
Weight	
Auslösekraft	50 g
Release force	

---

### Benutzerumgebung

### Environmental condition

Betriebstemperatur	0 °C – 48 °C
operating temperatur	

---

<b>Artikelnummer</b>	520312 (rechts/right)
<b>Article number</b>	520322 (links/left)

---

## Produktbeschreibung / Anwendung

### Product description / usage

Das Taster Pad – rechts bzw. links ist für Rechtshänder bzw. Linkshänder konzipiert. Der Daumen Auslöser kann je nach Vorliebe frei positioniert werden. Zum Auslösen ist lediglich eine Kraft von maximal 50 g notwendig.

*The Trigger Pad - right or left is designed for right-handed or left-handed users. The thumb trigger can be positioned freely according to preference. A force of only 50 g maximum is required for release*

## Clip Pad Montageanleitung

### Clip Pad mounting instructions

Das Trigger Pad mit 3 Schrauben und 3 Beilagscheiben, wie in der Abbildung unten, am HS 50 montieren.

Anzugsmoment: 0,3 Nm

*Please, assemble the Trigger Pad with the 3 provided screws and discs, shown in the figure below, to the HS 50.*

Torque: 0.3 Nm

